

FME ADAPTORS



2821 SERIES.

<p>PLUG – PLUG</p>	<p>FME PLUG – BNC PLUG</p>	<p>FME PLUG – BNC PLUG RIGHT ANGLE</p>
<p>2821-10501 (50Ω)</p>	<p>2821-10502 (50Ω)</p>	<p>2821-10503 (50Ω)</p>
<p>FME PLUG – TNC PLUG</p>	<p>FME PLUG – TNC PLUG RIGHT ANGLE</p>	<p>FME PLUG – N PLUG</p>
<p>2821-10504 (50Ω)</p>	<p>2821-10505 (50Ω)</p>	<p>2821-10506 (50Ω)</p>
<p>FME PLUG – UHF PLUG</p>	<p>FME PLUG – SMA PLUG</p>	<p>FME PLUG – MINI UHF PLUG</p>
<p>2821-10507 (50Ω)</p>	<p>2821-10508 (50Ω)</p>	<p>2821-10509 (50Ω)</p>
<p>FME PLUG – PLUG STRAIGHT ANGLE</p>	<p>JACK - JACK</p>	<p>FME JACK – TNC PLUG</p>
<p>2821-10510 (50Ω)</p>	<p>2821-10511 (50Ω)</p>	<p>2821-10513 (50Ω)</p>